

Telecommunications Equipment Catalog

2009-2010

Equipment for Deaf Blind



T08

Superprint Pro80 LVD TTY

The Superprint Pro80 LVD is ideal for people with low vision. It has all the same great features as the Superprint Pro80 but with a larger display. A large one-line, 20-character display is built right into the TTY!

Vendor Awarded: Harris Communications Inc.

True-size computer-style keyboard

Extra large screen display that increases text size to approximately 1 inch, more than twice the size of a standard TTY display

Large print option which allows users to select from four different print sizes.

Function key overlay with large print for easier reading

Optional amber or rose screen colors available

Large print manual, Convenient "GA" and "SK" keys, 11 special "one-touch" function keys

Arrow keys for easy review of conversations, Turbo Code®, Auto ID

Direct connects to telephone line, Call Progress, One-touch dial key

32K memory to save memos, conversations and phone numbers

One-touch Greeting Message key (user-programmable message)

Save and print messages with Auto-Answer, Remote message retrieval

Built-in Caller ID (for those with Caller ID service), TTY Announcer, Supports 3-way calling

Built-in ring flasher, Uses standard size 8-1/2" wide thermal paper



T09

Krown MP2000DLVD

This device, with Large Visual Display, is generally used by deaf, hard of hearing and vision impaired for comfortable reading. The Large Display shows words larger than words on a standard TTY display

Vendor Awarded: Harris Communications Inc.

Fast type: for “real time” conversation, Large Display shows words larger than standard TTY (choose between 3 print sizes)

Separate ON/OFF printer switch, Memory dialing, Built-in directory, Programmable relay number, Auto answer, Remote message retrieval TTY alert, Visual display of dial tone, busy and ring, Interrupt,

Appropriate for persons with low vision and severe-profound hearing loss and/or speech difficulties

20-character display, 24-column printer with three print sizes, Upper and lower case printing, 32K Memory, Built-in help menu, Four message buffers, Electronic voice Keyboard & Memory dialing, Tone/Pulse dialing mode



TB1

Krown Vtouch Braille-TTY Phone

Communication with Krown VTouch TTY will be faster and more convenient for the Deaf-Blind. (allows telephone and face to face communication)

Vendor Awarded: Teltex Inc.

Keyboard: 2 modes: Braille with soft-switch and QWERTY keypad

Directly connects to the telephone line or acoustically couples to telephone handset

Portable Vtouch unit is 3 lbs, connects to telephone line (Relay). Automatically answers and displays call on Braille display. Call recorded in internal memory.

20 cells and second fill type keyboard for face to face conversation

Automatic answering machine with remote message retrieval (password protection)

Wireless tactile pager for incoming call notification

2 tactile signalers for outgoing call progress

Communicate via Relay Operator, another TTY or Braille-TTY user worldwide



20 cell-TB3 or 40 cell-TB4
PACMATE/FSTTY TELEPHONE COMBO
(20 or 40 cell display)

Deaf-Blind PAC Mate users will benefit from Freedom Scientific's FSTTY application when placing and receiving telephone calls via TTY and using a 20-cell or 40-cell braille display, PACMATE.

Vendor Awarded: CNI Systems

The FSTTY package includes a TTY modem and power supply, the FSTTY application CD, a serial cable, Socket Communications serial I/O CompactFlash card, a telephone cable, and leather carry case. FSTTY delivers convenient telephone support for deaf-blind users, as well as other great features:

Pass information along to others quickly and efficiently during a TTY call. Just copy and paste text from your PAC Mate files or information from your PAC Mate Contacts or Calendar into FSTTY, and it will be automatically sent to the other party during a TTY call.

Easily and quickly copy text from entire phone conversations or portions of conversations and paste into other PAC Mate files.

Keep safe and accurate records of your TTY conversations. Launching FSTTY opens a temporary file to which all session activity is recorded. This file can be saved at any time during the session as a permanent file on your PAC Mate.



V06

JV-35 Amplified Phone by Clarity

The JV35™ amplified phone, by Clarity®, features Clarity® Power™ technology to make words not only louder, but also clearer and easier to understand. With large high-contrast buttons and up to 37 decibels of amplification, the JV35™ is an ideal solution for those with a moderate hearing loss or low vision.

Vendor Awarded: Tele-Communications Inc.

Clarity® Power™ technology, Amplifies incoming sounds up to 37dB

Adjustable volume and tone control, High contrast, jumbo-size buttons with Braille characters

Electronic voice repeats each number as it is dialed

10 programmable memory buttons announce the name you are calling - prerecorded in your own voice!

3 one-touch dedicated programmable emergency memory buttons with Braille characters

Adjustable Tone Selector, Extra loud ringer with a choice of ringing tones

Bright visual ring flasher, Audio output jack, Hearing aid compatible

Neckloop compatible, Redial, Hold and Flash buttons

AC adapter with battery back-up (battery not included)

16 cell-TV1 or 32 cell-TV2 DeafBlind Communicator (18 cells or 32 cells)



SMS Texting to Other Cell Phone Users Text messaging is fast becoming one of the most frequent forms of communication between cell phone users. A SIM card can be purchased from a wireless provider and installed in the DB-Phone. When activating a TTY call, DBC users can choose to activate the DB-Phone to send text messages.

Vendor Awarded: HumanWare

The DBC is designed to be simple and straight forward with the goal of enabling any Braille user to learn to use it with minimal training. The DBC uses a condensed form of BrailleNote mPower's notoriously friendly user interface called KeySoft. Easy-to-use menus enable users to quickly find the applications they need and context sensitive "help" is always available in every application to guide and remind the user of options and commands. Activating mPower Applications Those users who are ready for a more sophisticated system can choose to activate the full power of the BrailleNote mPower. Applications like a word processor with spell checker, planner, email, Internet browser, and bookreader are among the applications included once activated.